

PRODUCT Mobile Computers

CATEGORY OS

QUESTION Could you tell me how to upgrade to the other OS version?

ANSWER There are two ways to upgrade it by the "Active sync" and the "SD card"
You can find a manual for upgrading in "Download" page.
(Download -> OS image -> Pidion -> OS upgrade)
And it is different for each terminals to go to the ULDR Menu.

- * BIP-5000 with WM5.0 => Fun + 3 + reset
- * BIP-5000 with CE5.0 => Fun + 3 + reset
- * BIP-1300 with WM5.0 => Fun + 3 + reset
- * BIP-1300 with CE5.0 => Fun + 3 + reset
- * BIP-1250 with CE4.2 => 7 + 8 + reset
- * BM-150-R => Send + End + reset
- * BM-500 with GSM => 1 + reset

PRODUCT Mobile Computers

CATEGORY ETC

QUESTION Is there a way to hard reset the terminal to factory settings and delete all the programs that have been installed on the terminal?

ANSWER It is possible to get a RAM clear mode(hard reset) to back to the factory setting.
(Hold two buttons and reset then take off the reset button only when you see the title as 'Pidion' on the screen. And then take off two buttons as well.)
It is different for each terminals as follows.

- * BIP-5000 with WM5.0 => Fun + 6 + reset
- * BIP-5000 with CE5.0 => Fun + 6 + reset
- * BIP-1300 with WM5.0 => Fun + 4 + reset
- * BIP-1300 with CE5.0 => Fun + 6 + reset
- * BM-150-R => Send + OK + reset
- * BM-500 with GSM => # + * + reset

PRODUCT Mobile Computers

CATEGORY IC_READER

QUESTION Could you let me know the specification for RF reader which type is supported on BIP-1300?

ANSWER * **RF reader on BIP1300**

1.Type: 13.56Mhz ISO14443 type A & B and Mifare supported

2. Manufactured by GemProx

3. Mifare

This product,BIP-1300, supported all types of Mifare such as ;°Mifare Standard,

Mifare 4K, Mifare Pro, Mifare Ultralight, Mifare DESFIRE, Mifare SmartMX;±.

4. Reference

If you might meet some unreadable situation, it may be that there;¯s some security key in its specific Mifare cards therefore if you know the security key, you can read all of it.

PRODUCT Mobile Computers

CATEGORY Development

QUESTION What should I choose a development tool to develop an application with Pidion

ANSWER * Windows CE5.0 Devices

=>We recommend tools that EVC++4.0 & VisualStudio2005 C#

* Windows Mobile 5.0

=>We recommend tools that VisualStudio2005 C++ & C#

We already provide SDK as each OS and development tool. Please go to [DOWNLOAD](#) page and you can find it also download it.

PRODUCT Mobile Computers

CATEGORY Modem firmware

QUESTION Could you tell me how to upgrade to the new modem firmware?

ANSWER You can find a manual and firmware file with the upgrading tool in the "Download" page.
(Download page -> Choose an option -> Modem firmware)

* **Telit Modem firmware for BM-150r**

* **Wavecom Modem firmware for BIP-5000, BIP-1300, BM-500**

PRODUCT Mobile Computers

CATEGORY PRINTER

QUESTION I would like to print out a picture with Pidion included printer. Is it possible?

ANSWER Yes! You can print a bitmap file with Pidion such as BIP125X and BIP1300.
But there is a condition to print a bitmap.
The bitmap file should be mono color image.
Please find a test sample bitmap file attached.

DOWNLOAD [DOWNLOAD] : test.bmp

PRODUCT Mobile Computers

CATEGORY Modem firmware

QUESTION We have tried to perform the modem firmware update and a software OS update on Pidion, It has failed and the device will not boot up anymore.

ANSWER It seems that is not correct which you have updated them to your unit.
Please make sure the PDA type what it has the GSM modem.

< **Product type with GSM Modem**>

* **BIP-5000-5 / BIP-5000-7**

* **BIP-1300-G / BIP-1300-K / BIP-1300-M / BIP-1300-N**

* **BM-150R-A / BM-150R-B**

PRODUCT WIRELESS LAN



CATEGORY WIRELESS LAN



QUESTION [WiFi]How do I check status of Wireless LAN



ANSWER Checking an wireless lan status

- [HKEY_LOCAL_MACHINE\System\State\Hardware]

"Wifi"=dword:00000005

(- À\$ Key ,! notification broker,! »ç¿ëÇİç© wifi °aÀÇ °- °æ ½Ã event,! 'PÀ» ¼ö ÀÖÀ,,ç. event ¼ö½Å½Ã °aÀ» ÀÐ¾¼i »óÅÅ,; Å¼Å©ÇÒ ¼ö ÀÖ½À ÍÙ.)

- You can receive an event from using notification broker with above registry key when the wifi change status, after then you can check status of wifi.

- refer to MSDN

* <http://msdn2.microsoft.com/en-us/library/bb154491.aspx>

* Sample : <http://msdn2.microsoft.com/en-us/library/bb154479.aspx>

- Value of status flags.

=====

Status Flags Description.

=====

WSF_POWER_ON (0x00000002) Wi-Fi is currently powered on.

WSF_CONNECTING (0x00000008) Wi-Fi is connecting to selected network.

WSF_CONNECTED (0x00000010) Wi-Fi is connected.

WSF_HARDWARE_PRESENT (0x00000001) Wi-Fi hardware is present on the device.

WSF_NETWORKS_AVAILABLE (0x00000004) Wi-Fi networks are available.

=====

PRODUCT Mobile Computers



TITLE How do I compute a battery time?



CONTENT A formula : Battery Capacity / Power consumption = Battery time

Ex)BIP1300(2000mAh). Idle mode(back light off. all Radio off) and plus play a motion picture(AVI file).

==> 2000/(80+60)=14.28=14+(28/100X60)=14 hours 16 minutes

Please refer to attach file.

FILE [DOWNLOAD] : [Battery_Time_Jay_Kim.xls](#)

PRODUCT Mobile Computers

CATEGORY ETC

QUESTION How much power does the USB Host interface on the BIP-1300 provide?
The customer needs to know the voltage and max amperage of the power supply via USB Host.
What kind of card reader / PED has been used and how did they get power?

ANSWER USB mini port combined BIP1300 has USB Host standard specification.
5V / 500mA

PRODUCT Mobile Computers

CATEGORY ETC

QUESTION What is the power used by the FM transmitter (in milliWatts)?
It is not high enough and that he needs to put it in the back of the car until his radio picks up a signal.

ANSWER The power is -60~-65dBm.
And it is impossible to raise up the power because the CE and FCC standard certificated is low.

PRODUCT Mobile Computers

CATEGORY PRINTER

QUESTION We are trying to Print accented letter (like é, è, à) with BIP1300 printer. Is there any possibility to print these characters?
What do I need to do to have accented characters?

ANSWER

Please try to print the accented characters after copy the attached all files into the BIP-1300 \ programstore \ font.

Remember that these files are the only sample to print from Font_accentuated_characters_.zip.

This is not by default in device programstore/fonts directory.

1. Copy these all files into programstore/font.
2. Execute the sample program with VS2005.
3. Edit(input) the content to print the accented character then compile.
4. Try to print

DOWNLOAD [DOWNLOAD] : [Font_accentuated_characters_.zip](#)

PRODUCT Mobile Computers

CATEGORY CAMERA

QUESTION

How do I get the image to save as a Landscape image? I tried to set `m_CameraParam.rotation = rotation_degree.rotate_180;` and it saved a Landscape image, but not the same one in the Preview pane.

ANSWER

If you want to control the preview option please reference these parameters as follows.

```
m_CameraParam.preview_x = 0; => start point = x  
m_CameraParam.preview_y = 26; => start point = y  
m_CameraParam.preview_width = 200; => width  
m_CameraParam.preview_height = 200; => height
```

PRODUCT Mobile Computers

CATEGORY BATTERY

QUESTION

I have checked that a Power status of BIP-1300 is fully-charged of both main battery and backup battery. However, when i change the main battery, the BIP-1300 must be warm-boot. How can i solve this problem?

ANSWER That is not problem and normal status for the GSM modem.
The warm boot is for the GSM modem when you you change the main battery.
It is defined with all product from Bluebird soft.

PRODUCT Barcode Scanners

CATEGORY BARCODE SCANNER

QUESTION Can we use the datacollection.xml in the windows directory for the barcode setting?

ANSWER Yes, it is possible to use the the datacollection.xml.
But you must note that is allowed to change the value of the text or the default setting from the true to false.
It is important if you change the parameter type or the value it may be that there is a problem because the decoder engine is worked by reference to the setting value.